

Sponge-Jet® Sponge Blasting System

Sponge-Jet Continuous VAC-™ Recovery System User Manual

**Model
CVR-P220**



Headquarters/Manufactured By:

Sponge-Jet, Inc. (USA)

14 Patterson Lane, Newington, NH 03801

1-603-610-7950 / www.spongejet.com

Table of Contents

Section		Page
1.0	Introduction	3
2.0	Safety Checklist	5
3.0	Assembly	6
4.0	Requirements	17
5.0	Operation	18
6.0	Troubleshooting	21
	Notes	22

1.0 Introduction





Basic Components

- 1: Vacuum Hose Connection
- 2: Cyclone Hopper
- 3: First Stage Recovery Cyclone Hopper
- 4: Timer-Control Panel
- 5: Vacuum Pressure Transfer
- 6: Clamps
- 7: Second Stage Recovery Cyclone Hopper
- 8: Adjustable Frame
- 9: Recycler Drop-Out Transition

Basic Components *(continued)*

- 10: **Internal Vacuum Source Hose**
- 11: **Vacuum Ejector**
- 12: **Main Air Ball Valve**
- 13: **Supply Line Connection**
- 14: **Vacuum Filter Silo**
- 15: **Automatic Purging System**
- 16: **Vacuum Pressure Gauge**
- 17: **Differential Pressure Gauge**
- 18: **Frame Height Locking Pin**
- 19: **Sleeve Assembly Locking Pin**
- 20: **Frame Height Adjustment Handle**
- 21: **Vacuum Dust Bin**




2.0 Safety Checklist

- This Unit is a pressurized system. Only trained operators should adjust, maintain and repair this equipment.
- Inbound pressure should never exceed 7bar(100psi).
- To prevent electrostatic buildup and possible electric discharge, the unit must be properly grounded / bonded.
- Operators and people in proximity to blasting should always wear eye and hearing protection with the appropriate respiratory equipment and clothing, which may depend on the type of coating or contaminant being removed.
- All pneumatic lines should be inspected for holes, wear and proper fit.
- Safety pins and restraints should be fitted at all Supply Air Hose couplings to prevent accidental disconnection.
- Verify the unit is stable, secure and on a flat surface.
- Before all activities (other than normal operation), ensure the entire system is depressurized.

IMPORTANT: Under **NO** circumstances should any inspection, adjustment or lubrication be conducted while running or connected to an air supply.


3.0 Assembly





Insert the **Frame Height Locking** pin, secure with clevis pin






Insert the **Frame Height Locking** pin, secure with clevis pin







Lifting strap
should be rated
minimum 453kg
(1,000lbs)










Tighten jack before raising frame to desired height



Check **Clamps** are engaged







Connect **Timer
Control Panel
Pressure Line** to
**Automatic Purge
System**



Connect **Vacuum Hose**



Connect Internal **Vacuum Source Hose**



4.0 Requirements

4.1 Air Supply/Compressor

Clean, dry compressed air must be supplied. This unit requires a minimum air supply of **4.1nm³/min (145cfm)** supply air at 7bar(100psi).

4.2 Air Supply Connection

This unit uses a 32mm (1.25in) National Pipe Thread (NPT) fitted with a 32mm (1.25in) universal 4 lug coupling. The air supply hose should be fitted with a mating connector or replace both connectors as desired.




Connect a minimum 32mm (1.25in) supply hose to **Supply Line Connection**. **Note:** High humidity environments require additional moisture separators.

5.0 Operation

Before Recycler Pressurization and Operation:

- Verify the unit is stable, secure and on a flat surface.
- All pneumatic lines should be inspected for holes, wear and proper fit.
- Safety pins and restraints should be fitted at all Supply Air Hose couplings to prevent accidental disconnection.
- Before all activities (other than normal operation), ensure the entire system is depressurized.

Check that all **Clamps** are engaged.



Connect air supply hose to **Supply Line Connection** and secure with safety pins and restraints




Adjusting Frame Height: Remove **Frame Height Locking** Pin (both sides)




Turn **Frame Height Adjustment Handle**; raise or lower frame to desired height



Re-install **Frame Height Locking** Pin (both sides)



**IMPORTANT:
DO NOT REMOVE**
Sleeve Assembly Locking Pin
(for disassembly only)



Position **Sponge-Jet Recycler™**
under **Recycler Drop Out**

Activate **Sponge-Jet Recycler** with
containers under downspouts





Open **Main Air Ball Valve**



Vacuum **Sponge Media™**



6.0 Troubleshooting

Unit won't turn on	<p>Ensure air supply is maintaining a minimum of 7bar(100psi). Note: pressures higher than recommended, gradually reduce vacuum performance.</p>
Unit won't vacuum	<p>Check for clogs in Vacuum Hose and remove.</p> <p>Check filter, remove and replace if necessary</p> <div data-bbox="841 716 1479 1272">  </div>
Vacuum doesn't drop out material	<p>Check to see if Timer Control Panel switch is in "ON" position</p> <div data-bbox="1078 1318 1479 1612">  </div>

NOTES: _____

MODEL#: _____

SERIAL#: _____